

Auto-Trigger Mode for Follett 5300 / 6300 Scanners

Technical Support Knowledgebase Article

Product:5300/6300 Scanners	Destiny	Version:	N/A
-------------------------------	---------	----------	-----

Applies to:

Follett 5300 Corded and 6300 Cordless Scanners / Model # [Z31XX]

Symptoms:


A customer may want to enable Auto-Trigger mode for their scanner.

Solution:

1. Start by scanning the 'Start of Configuration' barcode.
2. Scan 'Trigger Mode' to return the scanner to standard operation, or scan 'Auto Scan Mode' for hands free operation.
3. Scan the 'End of Configuration' barcode. The unit is now in the desired mode of operation.





Start Of Configuration

End Of Configuration 

General Scan Mode Setting

Handheld Operation

Barcode Value	Barcode Label	Description
SM01		Trigger Mode <ul style="list-style-type: none">• The scanner becomes inactive as soon as the data is transmitted. It must be triggered to become active again.
SM02		Auto Scan Mode <ul style="list-style-type: none">• The scanner is still active after the data is transmitted but the successive transmission of the same barcode is not allowed when the trigger switch is pressed again.

Attribution:

Last updated:

11/29/2012

Author:

Sims, Clark

Contributions by:

Hamilton, Bruce

